BRAVOLL[®] PTH-X





Anchor type BRAVOLL®	Code	Total length L _a (mm)	max. insulation thickness h _D (mm) New ¹⁾	max. insulation thickness h _D (mm) Renovation ²)	Quantity per carton (pcs)
Base material categories:			A - B - C - D		
PTH-X 115		115	70	50	200
PTH-X 135		135	90	70	200
PTH-X 155		155	110	90	200
PTH-X 175		175	130	110	200
PTH-X 195		195	150	130	200
PTH-X 215		215	170	150	100
PTH-X 235		235	190	170	100
PTH-X 255		255	210	190	100

 $^{()}$ For a 35 mm embedment and 10 mm of glue (a_2) $^{(2)}$ For a 35 mm embedment, 20 mm of old render (a_1) and 10 mm of glue (a_2)



Technical data

Anchor type BRAVOLL®	PTH-X	
Base materials	characteristic resistance N _{RK} (kN)	
Concrete C 12/15 acc. to EN 206-1	0.60	
Concrete C 16/20 - C 50/60 acc. to EN 206-1	0.75	
Solid clay bricks acc. to EN 771-1	0.75	
Sand-lime solid bricks acc. to EN 771-2	0.75	
Hollow blocks from aerated concrete acc. to EN 771-3	0.60	
Lightweight aggregate concrete acc. to EN 1520 (LAC)	0.50	
Perforated clay bricks acc. to EN 771-1	0.50	
Vertically perforated clay bricks acc. to ÖNORM B6124	0.40	
Minimum edge distance c _{min} (mm)	100	
Minimum spacing s _{min} (mm)	100	
Minimum thickness of member h (mm)	100	

*) Based on a safety coefficient yof 3

Drawing



Anchor length calculation

$L_a \ge h_D + h_{nom} + max a_1 a max a_2$ d_o - plate diameter

- L_a anchor length
- h_{D} ins. material thickness
- h_{nom}- minimum embedment
- h_{ef} effective embedment depth
- h₁ minimum drilling depth
- a₁ render thickness
- a₂ gluing mortar thickness + fasade surface flatness tolerance



Installation



- Drill a hole through the insulation board to the right diameter. Hollow bricks should be drilled without hammering (ideally with a specially designed drill bit).
- Insert the anchor into the hole with the anchor plate flush in contact with the insulation material. Slightly hammer the anchor plate in order to push it between 0 and 2 mm under the insulation material surface.
- If the anchor is difficult to set, it probably means that the used drill bit is worn (the drilled diameter is too small or the dust remains inside the hole). It is then necessary to use a new drill bit or better clean the hole.
- Hammer the head of the pin until it becomes flush with the anchor plate.
- A 800g hammer is recommended to perform an optimal installation.
- Within 6 weeks the anchors should be covered by the other ETICS components (for UV protection).
- Installation must be done at a temperature > 0°C.